

OBHWA-T500 INSTALLATION INSTRUCTIONS



TOOLS REQUIRED:

- 10MM SOCKET WRENCH OR NUT DRIVER
- TWO (2) AA BATTERIES

General guidelines for installation of the OBHWA-T500 Wireless Adapter to an OBH500 OZ Electric Builder's Hoist.

STEP 1




Before you begin, check to ensure all components are included. Contact OZ Lifting Products to report missing parts.

- Receiver
- Mounting bracket with bolt and cotter pin
- 10mm hex head bolt
- Washer
- Wireless remote

NOTE: Batteries not included.

STEP 2



Mount the bracket to the receiver as shown. Do not over-tighten the 10mm hex head bolt as it may damage the housing.



STEP 3



Remove the cotter pin and nut from the mounting bolt. Ensure that the bracket arms of the receiver are on the outside of the bracket on the hoist itself. Insert the mounting bolt, reinstall the nut and cotter pin as shown below.

STEP 4



Insert and tighten the 5-pin male connector of the receiver cord into the 5-pin female connector on hoist body. It is advised to tie-up the wiring with zip ties to reduce the possibility of damage.

STEP 4



Insert the 3-pin female power connector to the 3-pin male connector on body as shown.

STEP 5



Carefully peel protective rubber sleeve back on the wireless remote, going over the top of the E-Stop.

Remove the two (2) screws on the battery compartment and insert the two (2) AA batteries, paying close attention to correct polarity.

Replace battery compartment cover and screws. Gently work protective rubber sleeve back into position.

Disengage E-Stop and press the green START button to operate the hoist.

COMPLETE



Your OZ Electric Builder's Hoist Wireless Adapter is now ready to use. Please follow the instructions in the operator's manual for further details. If you have any questions, please contact OZ Lifting Products.